


HYUNDAI
POWER PRODUCTS



18V CORDLESS DRILL HY2175

User Manual



INDEX

	CONTENTS	PAGE NO.S
1	SAFETY	3 - 11
2	PART LOCATIONS	12
3	OPERATION	13 - 16
4	MAINTENANCE	17
5	STORAGE & TRANSPORTATION	17
6	SPECIFICATION	17
7	RECYCLING & PRODUCT DISPOSAL	18
8	DECLARATION OF CONFORMITY	19
9	CONTACT DETAILS	20
10	WARRANTY	20
11	MANUAL UPDATES	20

1. SAFETY

1.1 General Safety Notes.

- 1.2 The operator of the machine is responsible for, and has a duty of care in making sure that the machine is operated safely and in accordance with the instructions in this user manual. Keep the manual safe and pass it on if the machine is loaned or sold to another user.
- 1.3 Please note the following safety points.
- 1.4 The machine should never be left it in a condition which would allow an untrained or unauthorised person/s to operate this machine.
- 1.5 All due care and diligence should be taken by the operator for the safety of and with regard to those around whilst using the machine.
- 1.6 Some or all of the following - warning signs, symbols and/or PPE pictograms may appear throughout this manual. You **MUST** adhere to their warnings. Failure to do so may result in personal injury to yourself or those around you.



DANGER

Indicates a hazard, which, if not avoided, could result in serious injury or death.



WARNING

Indicates a hazard, which, if not avoided, could result in serious injury.



CAUTION

Indicates a hazard which, if not avoided, might result in minor or moderate injury.



NOTE

Indicates a situation that could easily result in equipment damage.

READ and keep the manual safe and pass it on if the machine is loaned or sold to another user.

You **MUST** fully understand all instructions to ensure you use and operate the machine safely.

Appropriate Personal Protective Equipment (PPE), **MUST** be worn at all times when operating or repairing the machine.



HAND
PROTECTION
MUST BE WORN



EYE
PROTECTION
MUST BE WORN



PROTECTIVE
CLOTHING
MUST BE WORN



HEARING
PROTECTION
MUST BE WORN



FOOT
PROTECTION
MUST BE WORN



HEAD
PROTECTION
MUST BE WORN



RESPIRATOR
MUST BE WORN



FACE SHIELD
MUST BE WORN

DANGER!



BREATHING IN CARBON MONOXIDE FUMES CAN KILL YOU!

To help protect against CO poisoning install a Carbon Monoxide detector.



NEVER use Petrol/Diesel powered equipment inside, especially a home, garage, tent, camper-van, caravan, motorhome or boat.

EVEN if doors, windows, vents and hatches are open. Only use **OUTDOORS** and as far away from doors, windows, vents and open hatches as possible to prevent inhaling fumes.

READING MANUAL BEFORE USE WILL HELP AVOID OTHER MACHINE HAZARDS.

- 1.10 **Carbon Monoxide (where applicable).**
- 1.11 Carbon monoxide is a colourless and odourless gas. Inhaling this gas can cause death as well as serious long term health problems such as brain damage.
- 1.12 The symptoms of carbon monoxide poisoning can include but are not limited to the following;
Headaches, dizziness, nausea, breathlessness, collapsing or loss of consciousness.
- 1.13 Carbon monoxide poisoning symptoms are similar to flue, food poisoning, viral infections and simply tiredness. It is quite common for people to mistake this very dangerous poisoning for something else.
- 1.14 To avoid carbon monoxide poisoning **DO NOT** use Petrol/Diesel powered equipment inside any of the following; Home, garage, tent, camper van, mobile home, caravan or boat. This is not exhaustive and if you are in any doubt contact your dealer.
- 1.15 If you think you have or someone around you has been affected by carbon monoxide poisoning;
- 1.16 Get them fresh air immediately, by leaving the affected area or by opening doors and windows. If safe and practical to do so make sure that the machine is turned off.
DO NOT enter a room you suspect of having carbon monoxide present – instead call the emergency services.

1.17 Contact a Doctor immediately or go to Hospital – let them know that you suspect carbon monoxide poisoning.

1.18 **DO NOT** use in an enclosed area or moving vehicle.

1.20 General Fuel Safety (where applicable).



CAUTION

ALL FUELS ARE FLAMABLE

1.21 Fire Hazard – keep fuel away from all sources of ignition for example heaters. Lamps, sparks from grinding or welding.



1.22 **DO NOT** carry out hot work on tanks that have contained fuel.

1.23 **ALWAYS** keep the work area tidy.

1.24 **ALWAYS** clean up spills promptly using absorbent granules and a lidded bin.

1.25 **ALWAYS** dispose of waste fuels correctly.

1.30 Fueling/De-fueling (where applicable).



CAUTION

ALL FUELS ARE FLAMABLE

1.31 **ALWAYS** fuel and defuel in a well ventilated area outside of buildings.

1.32 **ALWAYS** wear correct, suitable and fit for purpose Personal Protective Equipment (PPE), suggested items are but not limited to safety gloves, overalls.



1.33 When fueling/de-fueling **ALWAYS** avoid inhaling fumes.

1.34 When de-fueling **ALWAYS** use a proper fuel retriever.



1.35 **ALWAYS** carry fuel in the correct and clearly marked container.

1.40 Electrical Safety (where applicable).

1.41 Electricity can kill – **NEVER** work on **LIVE/ENERGISED** equipment.

1.42 Prior to carrying out any maintenance work you **MUST** identify electrical isolation methods and isolate all electrical supplies.

1.43 Prior to use and with all electrical supplies isolated, you **MUST** check all electrical cables, plugs and connectors for the following;

- 1.44 Are intact and have no signs of damage, to include but not limited to bare wires, chaffing, cuts and loose wiring.
- 1.45 If there are any signs of damage, the damage item **MUST** be taken out of service until the damage has been repaired by an electrically competent person.
- 1.46 All trailing cables should be routed so as not to cause any kind of trip hazard.

1.47  **NEVER** work on or near electricity with wet hands, wet clothing and wet gloves.



1.50 Batteries (where present).

- 1.51 Batteries present a risk if they become damaged by the possible leaking of electrolyte. This electrolyte is an acid and can cause serious burn injuries. Care should be taken when working on or near them. **NOTE** the electrolyte may be in a liquid or gel form.
- 1.52 Should you come in to contact with electrolyte you should;
- 1.53 Remove all clothing contaminated with electrolyte. If you cannot remove then saturate them in water.
- 1.54 Get medical assistance as soon as possible. You must advise the medical staff of the type of acid.
- 1.55 Lead/acid battery = dilute sulphuric acid.
- 1.56 Nickel/cadmium = potassium hydroxide alkali electrolyte.
- 1.57 Use fresh running water to wash off excess electrolyte, continue this until medical assistance arrives. Make sure that you do not wash the electrolyte to another part of your body or face.
- 1.58 If electrolyte comes in to contact with Eyes the electrolyte needs to be immediately washed away with large amounts of water. Make sure that you do not wash the electrolyte to another part of your face or body.
- 1.59 Gasses from charging batteries are highly flammable and great care should be taken to charge in well ventilated areas.

1.59.1  There is an explosion risk if the battery terminals are short circuited, when connecting/disconnecting **ALWAYS** exercise great care so that the terminals or battery leads are **NOT** allowed to touch and cause a spark. **ALWAYS** use suitable insulated tools.



1.60 Vibrations (where applicable).

- 1.61 Prolonged use of hand held (operated) machines will cause the user to feel the effects of/from vibrations. These vibrations can lead to white finger (Raynaud's phenomenon) or carpal tunnel syndrome. This condition reduces the ability of the hand to feel and regulate temperature, causing numbness and heat sensations and may cause never damage and circulatory tissue death.
- 1.62 Not all factors that lead to white finger disease are known, but cold weather, smoking and other diseases that affect blood vessels and blood circulation as well as large and long-lasting impact of shocks are considered factors in the formation of white finger. Note the following to reduce the risk of white finger and carpal tunnel syndrome;

- 1.63 Wear gloves and keep your hands warm.
- 1.64 Take regular breaks.
- 1.65 All of the above precautions may help reduce the risk of white finger disease but not rule out the carpal tunnel syndrome. Long-term and regular users are therefore recommended to observe the condition of your hands and fingers. Seek medical attention immediately if any of the above symptoms should occur.

1.70 Noise (where applicable).

- 1.71 The operating noise of the machine can damage your hearing. Wear hearing protection such as earplugs or ear defenders to protect your hearing. Long-term and regular users are advised to have hearing checked regularly. Be especially vigilant and cautious when hearing ear protection because your ability to hear alarm warnings will be reduced.
- 1.72 Noise emissions for this equipment is unavoidable. Carry out noisy work at approved times and for certain periods. Limit the working time to a minimum. For your personal protection and protection of people working nearby it is also advisable for them to wear hearing protection.

- 1.73 See Certificate of Conformity section for Outdoor Noise declaration of conformity.



MACHINE SPECIFIC SAFETY

2.0 General Machine Safety.

- 2.1 Read the owner’s manual carefully to understand how to operate this machine properly.
- 2.2 You should **NEVER** use the machine when;
- 2.3 Wearing loose clothing, barefoot or sandals.
- 2.4 Under the influence of drink or drugs or as a result of having taken medication for cold or flu, or any other times when a possibility exists that your judgement might be impaired or that you might not be able to operate the machine properly and in a safe manner.
- 2.5 Suffering from exhaustion or lack of sleep.
- 2.6 When the ground is slippery or when other conditions exist which might make it not possible to maintain a steady posture.
- 2.7 At night, at times of heavy fog, or at any other times when your field of vision might be limited and it would be difficult to gain a clear view of the area.
- 2.8 During rain storms, lighting storms, at times of strong or gale force winds, or at any other times when the weather conditions might make it unsafe to use this product.
- 2.9 **NEVER** run the engine indoors. The exhaust gasses contain harmful carbon monoxide.

- 2.10 When using this machine for the first time and before actual work, you **MUST** learn how to handle the machine from an experienced or skilled person.
- 2.11 Limit the amount of time using the machine continuously to somewhere around 10 minutes per session and take 10 to 20 minutes of rest between sessions. Also try to keep the total amount of work in a single day limited to 2 hours or less.
- 2.12 **NEVER** allow children or anyone unable to fully understand the directions given in this manual to operate this product.
- 2.13 Make sure you keep this manual handy so you may refer to it whenever questions arise and ensure you pass this manual on if the machine is loaned or sold.
- 2.14 Hold the power tool by the insulated gripping surfaces when performing an operation that may come in to contact with hidden wiring. The drill coming into contact with a live wire may make exposed metal parts of the power tool give the operator an electric shock.
- 2.15 If possible, always use clamps or a vice to hold your work.
- 2.16 Always switch off before putting the tool down.
- 2.17 Ensure that the lighting is sufficient.
- 2.18 Do not put pressure on the tool, such that it slows the motor down. Allow the bit to screw without pressure. You will get better results and you will be taking better care of your tool.
- 2.19 Keep the area free of tripping hazards.
- 2.20 Only use accessory bits in good condition.
- 2.21 Before starting, check that there is sufficient clearance for the bit under the workpiece.
- 2.22 Do not touch the bit after operation. It will be very hot.
- 2.23 Keep your hands away from under the workpiece.
- 2.24 Never use your hands to remove dust, chips or waste close by the bit.
- 2.25 Rags, cloths, cord, string and the like should never be left around the work area.
- 2.26 Support the work properly.
- 2.27 If you are interrupted when operating the tool, complete the process and switch off before looking up.
- 2.28 Periodically check that all nuts, bolts and other fixings are properly tightened.
- 2.29 When using the tool, use safety equipment including safety glasses or shield, hearing protection, and protective clothing including safety gloves. Wear a dust mask if the operation creates dust.

2.30  **WARNING**

Some dust created by power sanding, sawing, and grinding, drilling, and other construction activities contains chemicals known to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

Lead from lead-based paints,

Crystalline silica from bricks, cement and other masonry products.

Arsenic and chromium from chemically-treated lumber.

- 2.31 Your risk from these exposures varies, depending on how often you do this type of work.
- 2.32 To reduce your exposure to these chemicals, work in a well ventilated area and work with approved safety equipment, such as dust masks that are specially designed to filter out microscopic particles.
- 2.33 Even when the tool is used as described, it is not possible to eliminate all residual risk factors. The following hazards may arise in connection with the tools construction and design:
- Damage to the lungs if an effective dust mask is not worn.
Damage to hearing if effective hearing protection is not worn.
- 2.34 To ensure the longest battery life and best battery performance, always charge the battery when the temperature is between 18-24°C.
- 2.35 Do not charge the battery pack when the temperature is below 0°C or above 40°C. This is important. Failure to observe this safety rule could cause serious damage to the battery pack.
- 2.36 Do not incinerate the battery pack, even if it is seriously damaged or can no longer hold a charge. The battery pack could explode in a fire.
- 2.37 A small leakage from the battery pack may occur under extreme usage or temperature. This does not necessarily indicate a failure of the battery pack. However if the outer seal is broken and this leakage comes into contact with your skin:
- Wash the affected area quickly with soap and water.
Neutralise the liquid with a mild acid such as lemon juice or vinegar.
Flush eyes with clean water for a minimum of 10 minutes and seek immediate medical attention.
- 2.38 Never attempt to open a battery pack for any reason. If the plastic housing of the battery pack breaks open or cracks, immediately discontinue its use and do not recharge it.
- 2.39 Do not store or carry a spare battery pack in a pocket or toolbox or any other place where it may come in to contact with metal objects. The battery pack may be short circuited causing damage to the battery pack, burns or fire.
- 2.40 If storing the battery pack, cover the terminals with a heavy insulation tape.
- 2.41 Batteries stored for a long period will discharge their charge.
- 2.42 Do not store or use the battery pack in locations where the temperature may reach or exceed 40°C.
- 2.43 Allow the battery pack to cool down after charging. Do not place in a hot environment or direct sunlight.

- 2.44 Only charge the battery with the charger supplied.
- 2.45 Do not immerse the tool in water or any other liquids.
- 2.46 When transporting batteries, make sure their contacts are protected and properly insulated.
- 2.47 Store batteries in a cool dry place away from direct sunlight and extremes of temperature.
- 2.48 The battery must be disposed of in the correct manner.
- 2.49 If the charger cord is damaged, it must be replaced with an authorised manufacture replacement.
- 2.50 Only charge the battery pack indoors.
- 2.51 If the battery is damaged, do not attempt to charge.
- 2.52 The charger is intended to charge the battery supplied only. Do not attempt to charge any other battery using this charger.
- 2.53 Do not place other items on top of the charger as this could cause overheating.
- 2.54 Remove the charger from the wall socket via the plug, do not pull on the cable.
- 2.55 Make sure the charger leads is positioned where it cannot be stood on or tripped over.
- 2.56 Do not plug the charger in to an extension cord. The improper use of an extension cord could cause a fire risk.
- 2.57 Do not use the charger if it has sustained any damage.
- 2.58 Do not disassemble the charger. Take it to an authorised service centre if service or repair is required.
- 2.59 To reduce the risk of electric shock, remove the charger from the plug socket before attempting to clean it.
- 2.60 Do not expose the charger to water, rain or snow.
- 2.61 Never attempt to connect two chargers together.
- 2.62 Never insert objects into the ventilation holes of the charger. This can cause overheating, electric shock or damage to the unit.
- 2.63 Correct Personal Protective Equipment (PPE) **MUST** be worn at all times when operating or repairing this machine. This should include but is not limited to;



- 2.64 **DO NOT** use this machine inside a confined space such as but not limited to a vehicle, house, garage, container, boat or building. Only use outside in a well ventilated area.
- 2.65 For air cooling a minimum of 1m is required all around the machine.
- 2.66 Maximum ambient temperature 40 degrees Celsius.
- 2.67 Fire risk- Fuel can expand and overflow in a hot environment or moving vehicle.
- 2.68 Explosion risk- LPG/ Petrol can leak and the vapour is heavier than air. Never store in confined spaces especially in a boat where the vapour/has will accumulate in the hull and create a high risk of explosion.
- 2.69 Carbon monoxide poisoning risk- Never run an engine in a confined space or poorly ventilated area. Keep the machine away from windows to prevent fumes entering the internal space. Carbon monoxide is produced by the engine and contained in the exhaust fumes. You cannot see it or smell it and it can kill you in minutes.
- 2.70 Never use inside a confined space with an exhaust extension. If the exhaust extension fails the escaping exhaust gases could kill you.

2. PART LOCATIONS



1	Drill Chuck	5	Direction Switch
2	Torque Control	6	On-Off Trigger
3	2 Speed Gear Switch	7	18v Battery
4	LED Work Light	8	89 Piece Accessory Kit



3. OPERATION



NOTE

Before operation, fully charge the battery for 3 to 5 hours.

CHARGING THE BATTERY

- 3.1 Check the accessories before use.
- 3.2 Fully charge the battery for between 3 to 5 hours, check using the battery indicator lights.
- 3.3 Press the battery check button:


Red	Battery too low
Red + Yellow	Battery half charged
Red + Yellow + Green	Fully charged



- 3.4 Remove the battery from the drill and plug into the battery charger.
- 3.5 Plug the battery charger in to the mains socket and turn on.
- 3.6 The charger will display a red light while charging and will turn green when fully charged.
- 3.7 Once charged, turn the charger off at the mains and remove the plug.

INSTALLING THE BATTERY

- 3.8 Press down on the battery release clip and remove the battery.



- 3.9 Ensuring the correct orientation between the battery and the battery compartment on the drill.
- 3.10 Insert the rechargeable into the drill.
- 3.11 Do not apply force when inserting the battery.
- 3.12 The battery must be inserted completely until the battery retention clips on the sides of the battery compartment and click into place.
- 3.13 To remove the battery, press in the retention clips and pull the battery from its compartment.

INSERTING DRILL BITS



CAUTION

Always remove the battery before you change the drill bits to avoid unintentional starting of the machine.

- 3.9 The cordless drill has a keyless chuck so you do not need a key to lock the bit in place.
- 3.10 Hold the drill and turn the chuck anticlockwise to open the jaws of the chuck.
- 3.11 Insert the bit so it sits straight in the chuck and not at an angle.
- 3.12 Hold the drill firmly and turn the chuck in a clockwise direction to close the jaws of the chuck onto the installed bit.
- 3.13 Reverse the procedure to remove the bit after use.

ON/OFF TRIGGER

- 3.14 Use the On/Off trigger to start the drill and keep it pressed for continuous operation.
- 3.15 The speed of the drill can be varied by how far in you press the On/Off trigger.
- 3.16 To stop the drill, release the On/Off trigger.

REVERSE ROTATION

- 3.17 Allow the drill to come to a complete stop otherwise the drill may be damaged.
- 3.18 Push the direction switch to select either forward rotation (clockwise) or reverse rotation (anticlockwise).

TRIGGER LOCK

- 3.19 Setting the direction switch in a central position, between forward and reverse rotation will lock the On/Off trigger so it cannot be depressed.
- 3.20 Use the trigger lock every time the drill is not in use to prevent accidental starting.

TORQUE ADJUSTMENT



NOTE

The torque control knob should only be operated when the drill is not in use. Adjusting the torque setting whilst the drill is running, may cause irreversible damage to the drill that will not be covered by the warranty.

- 3.21 To adjust the torque setting, allow the drill to come to a complete stop.
- 3.22 Turn the torque control to one of the 20+1 different torque settings depending on the type of job you are doing.
- 3.23 The lower the number the less amount of torque will be applied.
- 3.24 If you exceed the torque for the selected torque setting, the drill clutch will slip to prevent damage to the drill.
- 3.25 Turning the torque control to the image of a drill bit applies maximum torque with no clutch slip.

GEAR SWITCH



NOTE

The gear switch should only be operated when the drill is not in use. Adjusting the torque setting whilst the drill is running, may cause irreversible damage to the drill that will not be covered by the warranty.

- 3.26 The drill has a 2 speed gear selection switch.
- 3.27 Selecting gear speed 1 is for controlled screw driving and low speed work.
- 3.28 Selecting gear speed 2 is for drilling into masonry, wood and steel.

DRILLING

- 3.29 Check the drill bit is correctly inserted and fastened tightly before starting the drill.
- 3.30 Use properly sharpened drill bits designed for use with the drill.
- 3.31 At the start of each drilling, select a lower speed.
- 3.32 For large holes, drill a smaller pilot hole first and then enlarge the hole using a larger drill bit.

DRILLING WOOD

- 3.33 For drilling wood, use a drill bit designed for wood.
- 3.34 Protect or fasten the work piece in a suitable vice or holder.
- 3.35 Mark the position of the hole to be drilled with a sharp tool.
- 3.36 Do not apply excessive pressure against the work piece with the drill.

DRILLING METAL

- 3.37 For drilling metal, use a steel drill bit.
- 3.38 Always provide sufficient cooling with suitable non-flammable coolants.
- 3.39 Protect or fasten the work piece in a suitable vice or holder.
- 3.40 Mark the positions of the holes to be drilled with a centre punch.
- 3.41 Do not apply excessive pressure against the work piece with the drill.
- 3.42 Allow the drill to operate at its normal operating speed.

DRILLING PLASTIC

- 3.43 For drilling plastic, use a steel drill bit.
- 3.44 Follow the same instructions for drilling wood.

SCREWDRIVER

- 3.45 Check the screw bit is installed correctly.
- 3.46 Use a low gear and torque setting for more control.
- 3.47 Avoid over tightening screws otherwise the screw head may be damaged.
- 3.48 Use screwdriver bits that are not heavily worn.
- 3.49 Set the direction of the drill.
- 3.50 Insert the screw bit perpendicular to the head of the screw.
- 3.51 Start slowly and apply constant pressure.

SCREW REMOVAL

- 3.52 Set the direction of the drill to reverse.
- 3.53 Insert the screw bit perpendicular to the head of the screw.
- 3.54 Start slowly and apply constant pressure.

4. MAINTENANCE



CAUTION

Always remove the battery before carrying out any maintenance.

Do not disassemble the drill or charger unless you are qualified to do so.

If something unusual occurs during use, switch off the drill and remove the battery. Inspect and repair the tool before using it again.

Repair of the tool must only be carried out by a qualified repair technician.

- 4.0 Inspect the drill and charger for any signs of heavy wear or damage.
- 4.1 Damaged parts must be repaired or replaced before using the drill.
- 4.2 Keep the ventilation slots clear of dust and dirt.
- 4.3 Keep the drill clean and wipe over with a cloth on a regular basis.
- 4.4 Do not clean the drill with any solvent based cleaning products as this could damage plastic parts.

5. STORAGE & TRANSPORT


- 5.0 Store the drill, accessories and instruction manual in the original packaging.
- 5.1 Avoid areas of direct sunlight or varying temperature.
- 5.2 Do not stack other items on top of the drill.
- 5.3 Always store in a dry environment.

6. SPECIFICATION

Model	HY2175
Power	18v
Chuck	10mm Keyless
Battery	JH001-18v
	18v
	Li-Ion 1500 mAh
Speed	0-350 / 0-1300rpm
Torque Settings	20+1
Charging Time	3-5 hours
Maximum Drilling Capacity	Steel Ø 10mm
	Wood Ø 25mm
Sound Pressure Level	69.88 dB(A)
Sound Power Level	80.88 dB(A)
Drill Mode Vibration Level	$a_h = 0,685 \text{ m/s}^2$ $K = 1,5 \text{ m/s}^2$
Screwdriver Mode Vibration Level	$a_h = 1,030 \text{ m/s}^2$ $K = 1,5 \text{ m/s}^2$
Battery Charger	
Rated Input Voltage	220-240v 50/60Hz
Rated Input Power	0.3A
Rated Output Voltage	21.5v
Rated Output Current	0.4A

7. RECYCLING & PRODUCT DISPOSAL

- 6.0 We do not offer a takeback scheme for the recovery of Waste Electrical Electronic Equipment (WEEE) & Batteries.
Instead the responsibility to dispose of WEEE and or Batteries is passed onto you by us.
So when it becomes necessary to dispose of your machine you must take it to your local Civic Amenity Site.
For further information please contact your local Authority for disposal advice.
- 6.1 You **MUST** make sure that all unused oil and fuel is disposed of correctly either beforehand or at your local Civic Amenity Site.
Under NO circumstances must any fuel or oil be put down any drains.
- 6.2 Certain products contain WEEE waste which should not be disposed of in your domestic waste.
- 6.3 You **MUST** recycle WEEE in accordance with your local authority or recycling centre.
- 6.4 Certain products contain batteries which should not be disposed of in your domestic waste.
- 6.5 You **MUST** recycle batteries in accordance with your local authority or recycling centre.
- 6.6 Unwanted packaging and materials should be stored and taken to a recycling centre so it can be disposed of in a manner which is compatible with the environment.
- 6.7 The following symbol means that you should 'Reduce – Reuse – Recycle'.
- 6.8 We are a Member of the VALPAK National Compliance Scheme and our registration number is **RM08660**
- 6.9 For further information about disposal please contact your Local Authority.
- 6.10 You can also get more advice and guidance about recycling at the following website <http://www.recycle-more.co.uk>
- 6.11 Should you pass this product on to another user either sold or loaned, you **MUST** pass on this user manual.
This will make sure that all other users can use and maintain this machine safely.



8. DECLARATION OF CONFORMITY

EC Declaration of conformity

We hereby declare that the machine detailed in this declaration complies to all the relevant provisions of the following EC directives.

- 2006/42/EC The Machinery Directive
- 2014/30/EU Annex II Electromagnetic Compatibility Directive
- 2011/65/EU + (EU) 2015/863 RoHS
- Hand-held motor-operated electric tools. Safety.

And is in conformity with the applicable requirements of the following documents:

- EN 60335-1
- EN 60335-2-29
- EN 62841-1: 2015
- EN 62841-2-1:2018
- EN 55014-1:2017
- EN 55014-2: 2015
- EN 61000-3-1:2014
- EN 61000-3-3:2013

Model	Type	Motor Size	Voltage	Battery size	Chuck dia
HY2175	Cordless 18v drill	#550	18v	1500mah	10mm

Product Details

Brand: Hyundai

Model: HY2175

Description: Cordless 18v drill

Name and address of technical documentation holder and EU distributor:

Genpower Ltd, Isaac Way, Pembroke Dock, Pembrokeshire, SA72 4RW, UK.

Signed by:



Roland Llewellyn, Managing Director

Date: 22/07/2020

9. CONTACT DETAILS

7.0	POSTAL ADDRESS	Genpower Ltd, Isaac Way, London Road, Pembroke Dock, Pembrokeshire. SA72 4RW. UK.
7.1	TELEPHONE	+44 (0) 1646 687880
7.2	FAX	+44 (0) 0164 686198
7.3	TECHNICAL EMAIL	aftersales@hyundaipowerproducts.co.uk
7.4	WEBSITE	www.hyundaipowerproducts.co.uk

10. WARRANTY

- 8.0 Proof of purchase will be required before you make a warranty claim.
Full warranty terms and conditions can be found on the HYUNDAI POWER PRODUCTS website:
www.hyundaipowerproducts.co.uk

11. MANUAL UPDATES

- 9.0 Our manuals are constantly being reviewed and updated.
However if you find an error, omission or something you find unclear, please contact your dealer for assistance.
- 9.10 All our manuals are also available online.
- 9.11 We reserve the right to make any modifications without prior notice whenever necessary.

HYUNDAI

POWER PRODUCTS

Importer:

GENPOWER LTD

Isaac Way, London Road

Pembroke Dock, UNITED KINGDOM, SA72 4RW

T: +44 (0) 1646 687 880 F: +44 (0) 1646 686 198

E: info@hyundaipowerproducts.co.uk

www.hyundaipowerproducts.co.uk

Imported/Distributed by GENPOWER LTD for The United Kingdom & Ireland

Licensed by Hyundai Corporation, Korea